

Moda bed assembly

eUROFORM

Instructions

- ① Insert T-Bolt nut into holes in bed head and foot end panels.
Make sure thread is facing right direction.
- ② Starting with the bed head panel attach the bed side rail to the bed head with long T-Bolt screws. *Do not tighten.*
- ③ Repeat for other side rail.
- ④ Attach seat base to side rails.
- ⑤ Attach foot end to side rails.
- ⑥ Once all panels are in place tighten all the bolts with the Allen key.
- ⑦ Place slats in position and fix two slats to side rails with screws.

Hardware list

- 11 – T-Bolt nuts**
- 11 – T-Bolt screws**
- 4 – Screws**
- 1 – Allen key**

